

AUSSIE COAT

SEMI TRANSPARENT TIMBER COAT PRODUCT DATA SHEET



Description

AUSSIE COAT is a Water Based Semi-Transparent Acrylic designed for use on Outdoor Timbers such as Windows, Decking, Outdoor furniture and Doors. It has a slight pigmentation for UV protection but on many timbers will provide a transparent satin semi-gloss coat which will enable the natural features of timber to be seen.

Recommended Uses

AUSSIE COAT will protect the timber from weather and is flexible to allow some normal timber movement. AUSSIE COAT is recommended for popular timbers such as Cedar, Merbau, Cypress Pine, and Australian Hardwoods.

Surface Preparation

- Previously painted surfaces must be completely stripped back to bare timber.
- It is recommended to apply a timber cleaner (oxalic acid) such as Preschem GREY DECK CLEANER followed by powerwashing the timber surface.
- Timber with tanin, iron or mould stains needs to be sanded or treated with mould killers, such as Preschem D Mould, to ensure AUSSIE COAT has a clean timber surface to adhere to.
- **IMPORTANT;** This product is a timber coating and whilst it does penetrate it can trap foreign matters left on the timber surface. We cannot guarantee that tanin or mould may not develop under the surface of this coating at a later date. Timber is a natural product and can be unpredictable.
- We recommend applying 3 coats with the 1st coat applied on wet/damp timber.

First Aid and Safety Directions

Avoid skin contact by wearing protective clothing. Don't breathe vapour or spray mist and provide adequate ventilation. Keep out of reach of children. First Aid: If poisoning occurs contact a Doctor or Poisons Information Centre on 131126. Eyes: Hold eyes open, flood with water for at least 15 minutes. Swallowed: Give plenty of water to drink and seek medical advice.

Directions For Use

- Ensure a clean dry surface free from dirt grease and wax.
- Apply the 1st coat of AUSSIE COAT on wet or damp timber to enhance penetration of the mouldicide within the product. Apply liberally and allow to dry.
- Apply 2 further liberal coats of AUSSIE COAT.
- Allow 2 hours between coats and ensure surface is touch dry prior to re-coating.
- Mix well prior to application and during the application process.
- Application can be made with a pad type applicator and brushes. HVLP and airless sprayers can also be used for large vertical areas.
- Use of rollers is not recommended for application.
- Avoid lap marks by maintaining a wet surface in the application area.
- Application in temperatures above 32°C or below 8°C is not recommended. Application in direct sunlight may cause poor adhesion.
- Do not apply too late in the day and be careful of applications where rain may be expected within 6 hours.
- Surfaces that make contact with AUSSIE COAT such as doors may be sticky if not let to dry properly before re-contact

Restoration & Maintenance

- The condition of the coating should be assessed every 18 months.
- Further coatings should be applied prior to the coating breaking down (cracking or peeling)
- Clean area to be re-applied with powerwasher and reapply minimum 2 coats. The surface can be very slightly moist on the first coat.
- If the coating has broken down it is recommended to strip this back to raw timber before re-application.

Clean-Up

Application equipment is cleaned with water.

Coverage

Approximately 6-8m² per litre on rough sawn timber and 12-14m² per litre on dressed timber.

Packaging

Available in 1, 4 and 10 litre cans.

Manufactured by:

PRESCHEM Pty Ltd (A.B.N. 41 314 509 336)
Cheltenham, Victoria 3192
Toll Free: 1800 641 711
Website: www.preschem.com

